

A. Introduction

- 1. Title:** Reliability Coordination – System Restoration
- 2. Number:** EOP-006-0
- 3. Purpose:** The Reliability Coordinator must have a coordinating role in system restoration to ensure reliability is maintained during restoration and priority is placed on restoring the Interconnection.
- 4. Applicability**
 - 4.1.** Reliability Coordinator.
- 5. Effective Date:** April 1, 2005

B. Requirements

- R1.** Each Reliability Coordinator shall be aware of the restoration plan of each Transmission Operator in its Reliability Coordinator Area in accordance with NERC and regional requirements.
- R2.** The Reliability Coordinator shall monitor restoration progress and coordinate any needed assistance.
- R3.** The Reliability Coordinator shall have a Reliability Coordinator Area restoration plan that provides coordination between individual Transmission Operator restoration plans and that ensures reliability is maintained during system restoration events.
- R4.** The Reliability Coordinator shall serve as the primary contact for disseminating information regarding restoration to neighboring Reliability Coordinators and Transmission Operators or Balancing Authorities not immediately involved in restoration.
- R5.** Reliability Coordinators shall approve, communicate, and coordinate the re-synchronizing of major system islands or synchronizing points so as not to cause a Burden on adjacent Transmission Operator, Balancing Authority, or Reliability Coordinator Areas.
- R6.** The Reliability Coordinator shall take actions to restore normal operations once an operating emergency has been mitigated in accordance with its restoration plan.

C. Measures

Not specified.

D. Compliance

Not specified.

E. Regional Differences

None identified.

Version History

Version	Date	Action	Change Tracking
0	April 1, 2005	Effective Date	New
0	August 8, 2005	Removed “Proposed” from Effective Date	Errata